



REGULAR SERVICE PERIOD (1) Perform at every indicated month or operating hour interval, whichever comes first.		Each use	First month or 20 hrs.	Every 3 months or 50 hrs.	Every 6 months or 100 hrs.	Every year or 300 hrs.
Engine oil	A B	Check level Change	●	●	●	
Air cleaner	C D	Check Clean Replace	●	● (2)		● (3)
Sediment cup	E	Clean			●	
Spark plug	F	Check-adjust Replace			●	●
Spark arrester (applicable types)	G	Clean			● (5)	
Idle speed	H	Check-adjust				● (4)
Valve clearance	I J K	Check-adjust				● (4)
Combustion chamber	L	Clean		After every 500 hrs. (4)		
Fuel tank and filter	M	Clean			● (4)	
Fuel tube	N	Check		Every 2 years (Replace if necessary) (4)		

- (1) For commercial use, log hours of operation to determine proper maintenance intervals.
- (2) Service more frequently when used in dusty areas.
- (3) Replace paper element type only.
- (4) These items should be serviced by your servicing dealer, unless you have the proper tools and are mechanically proficient. Refer to Honda shop manual for servicing procedures.
- (5) In Europe and other countries where the machinery directive 2006/42/EC is enforced, this cleaning should be done by your servicing dealer.

