






Parts Manual

Mfg. No: 21R807-0072-G1

Model Components	Page
Alternator Group.....	4
Blower Housing and Air Cleaner Group.....	6
Carburetor and Fuel Supply Group.....	8
Controls Group.....	10
Crankcase Cover/Sump and Lubrication Group.....	12
Crankshaft Group.....	14
Cylinder Group.....	16
Cylinder Head Group.....	18
Exhaust Group.....	20
Flywheel, Ignition, and Starter Group.....	22

Not For
Reproduction



Alternator Group


REF NO	PART NO	QTY	DESCRIPTION
474	592829	1	ALTERNATOR
501	794360	1	REGULATOR
526	697088	1	SCREW -(Regulator)
578	692306	1	WIRE ASSEMBLY
1059	698516	1	KIT, Screw/Washer
1119	691183	2	SCREW -(Alternator)

Not For Reproduction

305B



304




305A




305



445



968




1319
1319A



1036



431



1266




964



Not For Reproduction


Blower Housing and Air Cleaner Group

REF NO	PART NO	QTY	DESCRIPTION
304	591641	1	HOUSING, Blower
305	596718	2	SCREW -(Blower Housing)
305A	799370	2	SCREW -(Blower Housing)
305B	795891	1	SCREW -(Blower Housing)
431	797901	1	ELBOW, Intake
445	591583	1	FILTER, A/C Cartridge
964	799159	1	CAP, Connector
968	591646	1	COVER, Air Cleaner
1036	-----	1	LABEL, Emissions -(Available from a Briggs & Stratton Authorized Dealer)
1266	691917	1	SEAL, O-Ring -(Intake Elbow)
1319	794467	1	LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1319A	797669	1	LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)



Carburetor and Fuel Supply Group




REF NO	PART NO	QTY	DESCRIPTION
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
53	591260	2	STUD -(Carburetor)
94	793610	1	KIT, Idle Mixture
95	690718	2	SCREW -(Throttle Valve)
98	695408	1	KIT, Idle Speed
104	694918	1	PIN, Float Hinge
105	696136	1	VALVE, Float Needle
108	698773	1	VALVE, Choke
117	791405	1	JET, Main -(Standard)
118	698788	1	JET, Main -(High Altitude)
121	796184	1	KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.)
125	593433	1	CARBURETOR
127	690727	1	PLUG, Welch
130	698774	1	VALVE, Throttle
131	698776	1	KIT, Throttle Shaft
133	694914	1	FLOAT, Carburetor
135	796400	1	TUBE, Fuel Transfer
137	698781	1	GASKET, Float Bowl
141	698778	1	KIT, Choke Shaft
187	791766	2	LINE, Fuel
187B	791805	1	LINE, Fuel
187D	791744	1	LINE, Fuel
217	695409	1	SPRING, Choke Return
240	84001895	1	FILTER, Fuel
276	695410	1	WASHER, Sealing
387	808656	1	PUMP, Fuel
601	791850	6	CLAMP, Hose
617	-----	1	SEAL, O-Ring -(Part information located in Cylinder Head Group.)
633	699813	1	SEAL, Choke/Throttle Shaft
633A	690998	1	SEAL, Choke/Throttle Shaft
634	698779	1	SPRING/SEAL ASSEMBLY
654	690958	2	NUT -(Carburetor)
773	796448	2	RETAINER
947	596038	1	SOLENOID, Fuel
975	699502	1	BOWL, Float
1127	695407	2	SCREW -(Float Bowl) (Float Bowl to Carburetor Body)
1139	796449	2	WASHER
1266	-----	1	SEAL, O-Ring -(Part information located in Blower Housing and Air Cleaner Group.)



Controls Group

REF NO	PART NO	QTY	DESCRIPTION
188	691693	2	SCREW -(Control Bracket)
202	691841	1	LINK, Mechanical Governor
209	792602	1	SPRING, Governor
216	691840	1	LINK, Choke
222	597209	1	BRACKET, Control
227	691374	1	LEVER, Governor Control
232	691842	1	SPRING, Governor Link
265	691024	1	CLAMP, Casing
267	794904	1	SCREW -(Casing Clamp)
505	691251	1	NUT -(Governor Control Lever)
562	691119	1	BOLT -(Governor Control Lever)
729	691224	1	CLIP, Wire
789	692037	1	HARNESS, Wiring

Not For Reproduction




Not For
Reproduction

Crankcase Cover/Sump and Lubrication Group

REF NO	PART NO	QTY	DESCRIPTION
4	697106	1	SUMP, Engine
12	697110	1	GASKET, Crankcase
15	690946	1	PLUG, Oil Drain
20	795387	1	SEAL, Oil -(PTO Side)
22	692125	10	SCREW -(Crankcase Cover/Sump)
43	691968	1	SLINGER, Governor/Oil
523	699908	1	DIPSTICK
524	691032	1	SEAL, O-Ring -(Dipstick Tube)
525	697085	1	TUBE, Dipstick
842	691031	1	SEAL, O-Ring -(Dipstick Cap)
847	790443	1	DIPSTICK/TUBE ASSEMBLY
850	100106	1	SEALANT, Liquid


Not For Reproduction



Not For
Reproduction


Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	593417	1	CRANKSHAFT
24	591757	1	KEY, Flywheel
25	595053	1	PISTON ASSEMBLY
25	595054	1	PISTON ASSEMBLY -(.020 Oversize)
26	797011	2	SET, Ring
26	792643	1	SET, Ring -(.020 Oversize)
27	698469	1	LOCK, Piston Pin
28	84002062	1	PIN, Piston
29	791633	1	ROD, Connecting
32	791118	2	SCREW -(Connecting Rod)
377	691639	1	KEY, Timing
45	690564	2	TAPPET, Valve -(Part information located in Cylinder Head Group.)
46	793880	1	CAMSHAFT
741	697128	1	GEAR, Timing
757	793242	2	LINK, Counterweight
758	593418	1	COUNTERWEIGHT
759	697392	2	PIN, Counterweight
1270	793243	1	PLUG, AVS Counterweight



Cylinder Group



REF NO	PART NO	QTY	DESCRIPTION
1	697377	1	CYLINDER ASSEMBLY
2	797673	1	KIT, Bushing/Seal -(Magneto Side)
3	391086S	1	SEAL, Oil -(Magneto Side)
7	-----	1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
11	794683	1	TUBE, Breather
12	-----	1	GASKET, Crankcase -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
306	592778	1	SHIELD, Cylinder
307	691693	2	SCREW -(Cylinder Shield)
358	796181	1	GASKET SET, Engine -(Service Kits may include extra parts not specific to this engine.)
404	691691	2	WASHER -(Governor Crank)
524	-----	1	SEAL, O-Ring -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
552	697144	1	BUSHING, Governor Crank
584	794682	1	COVER, Breather Passage
614	691620	1	PIN, Cotter
616	692012	1	CRANK, Governor
617	-----	1	SEAL, O-Ring -(Part information located in Cylinder Head Group.)
684	697157	2	SCREW -(Breather Passage Cover)
691	692407	1	SEAL, Governor Shaft
718	690959	2	PIN, Locating
842	-----	1	SEAL, O-Ring -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
868	-----	1	SEAL, Valve -(Part information located in Cylinder Head Group.)
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
1263	697124	1	REED, Breather
1264	697104	1	SCREW -(Breather Reed)
1266	-----	1	SEAL, O-Ring -(Part information located in Blower Housing and Air Cleaner Group.)



Not For
Reproduction

Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
5	796183	1	HEAD, Cylinder
7	273280S	1	GASKET, Cylinder Head
13	690360	6	SCREW -(Cylinder Head)
33	792868	1	VALVE, Exhaust
34	791935	1	VALVE, Intake
35	691279	2	SPRING, Valve -(Intake)
36	691279	2	SPRING, Valve -(Exhaust)
42	499586	2	KEEPER, Valve
45	690564	2	TAPPET, Valve
50	592845	1	MANIFOLD, Intake
51	692137	1	GASKET, Intake
54	691148	2	SCREW -(Intake Manifold)
192	691986	2	ADJUSTER, Rocker Arm
238	691843	2	CAP, Valve
337	555737	1	PLUG, Spark
383	19576S	1	WRENCH, Spark Plug
617	692138	1	SEAL, O-Ring -(Intake Manifold)
635	691909	1	BOOT, Spark Plug
718	690959	2	PIN, Locating
830	691095	2	STUD, Rocker Arm
850	-----	1	SEALANT, Liquid -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
868	690968	1	SEAL, Valve
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
914	691108	4	SCREW -(Rocker Cover)
1023	797421	1	COVER, Rocker
1026	697394	1	ROD, Push -(Intake)
1026	794573	1	ROD, Push -(Exhaust)
1029	691751	2	ARM, Rocker
1034	690822	1	GUIDE, Push Rod
1095	796189	1	GASKET SET, Valve -(Service Kits may include extra parts not specific to this engine.)








Not For
Reproduction

Exhaust Group

REF NO	PART NO	QTY	DESCRIPTION
81	691178	1	LOCK, Muffler Screw
300	795997	1	MUFFLER
613	691416	2	SCREW -(Muffler)
613B	690297	1	SCREW -(Regulator) (Muffler)
676	795036	1	DEFLECTOR, Muffler
677	690661	4	SCREW -(Muffler Deflector)
823	698941	2	SCREW -(Muffler Adapter)
864	796002	1	ADAPTER, Muffler
883	692236	1	GASKET, Exhaust

Not For Reproduction



Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	591760	1	FLYWHEEL
37	697352	1	GUARD, Flywheel
65	690940	4	SCREW -(Rewind Starter)
78	691693	2	SCREW -(Flywheel Guard)
309	593934	1	MOTOR, Starter
333	594626	1	ARMATURE, Magneto
334	691061	2	SCREW -(Magneto Armature)
356	697089	1	WIRE, Stop
363	19203	1	PULLER, Flywheel
455	796615	1	CUP, Flywheel
608	591606	1	STARTER, Rewind
635	691909	1	BOOT, Spark Plug
697	791680	2	SCREW -(Starter Motor) (Drive Cap)
1005	796200	1	FAN, Flywheel
1044	698139	1	SCREW -(Flywheel)

Not For Preproduction

