




Parts Manual

Mfg. No: 61E377-0009-J1


Model Components	Page
Air Cleaner, Purge Line Hose.....	4
Blower Housing, Oil Cooler, Tachometer, Key Switches.....	6
Control Brackets, Springs, Rod, Throttle Control.....	8
Crankcase Covers, Camshaft.....	10
Cyclonic Air Cleaner, Intake Elbow.....	12
Cylinder Heads, Rocker Covers.....	14
Cylinders, Piston/Rings/Connecting Rod.....	16
Electric Starter, Alternator, Regulator, ECM.....	18
Engine Gasket Set, Valve Gasket Set, Wire Cover Kit.....	20
Exhaust System, Oxygen Sensors.....	22
Flywheel Fans, Air Guides, Stub Shafts, Flywheel.....	24
Fuel Hoses, Fuel Pump, Mounting Bracket.....	26
Replacement Engine - US & Canada.....	28
Wire Harness, Throttle Body, Intake Manifold.....	29

Not For
Reproduction




Air Cleaner, Purge Line Hose

REF NO	PART NO	QTY	DESCRIPTION
11	846502		TUBE, Breather -(Formed Hose)
11A	847173		TUBE, Breather
163	807375		GASKET, Air Cleaner
163A	843117		GASKET, Air Cleaner
186	845121		CONNECTOR, Hose
431	846507		ELBOW, Intake
445	692519		FILTER, A/C Cartridge
467	846008		KNOB, Air Cleaner Cover
467A	846432		KNOB, Air Cleaner Cover
534	692062		SCREW -(Air Cleaner) (M8x18mm)
601E	846483		CLAMP, Hose -(Purge Line Hose)
643	844932		RETAINER, Air Filter
711	806444		SCREW -(Carburetor Shield) (M6x68mm)
875	843118		BASE, Air Cleaner
967	692520		FILTER, Pre Cleaner
968	841847		COVER, Air Cleaner
971	692062		SCREW -(Air Cleaner Base to Carburetor/Throttle Body)
996	846006		SHIELD, Carburetor
1425	847085		HOSE, Purge Line









Blower Housing, Oil Cooler, Tachometer, Key Switches

REF NO	PART NO	QTY	DESCRIPTION
239	841281		SWITCH, Oil Pressure
304	846481		HOUSING, Blower -(Oil Cooler)
305	807435		SCREW -(Blower Housing) (M6x20mm)
400	846249		COOLER, Oil
405	841233		SCREW -(Back Plate) (M6x10mm)
405A	841735		SCREW -(Back Plate) (M6x14mm) -Used After Code Date 15110200
415	794903		PLUG -(M6x10mm)
417	841233		SCREW -(Oil Cooler) (M6x10mm)
417A	846250		SCREW -(Oil Cooler) (M6x16mm)
500	691086		WASHER -(Key Switch)
506	692056		SCREW -(Carburetor/EFI Cover) (M8x14mm)
573	842712		PLATE, Back -(With Weld Nuts)
573A	846840		PLATE, Back -(Without Weld Nuts)
601A	841597		CLAMP, Hose -(Oil Cooler Hose)
601D	845209		CLAMP, Hose -(Oil Cooler Hose)
664	691087		NUT -(Key Switch)
668	841974		SPACER -(Blower Housing)
829	846247		HOSE, Oil Cooler
829A	846248		HOSE, Oil Cooler
879	846480		COVER, Carburetor/EFI -(Without Key Switch)
892	692318		SWITCH, Key -(Includes Key Switch Label)
990	691959		SET, Key
1059	845300		KIT, Screw/Washer -(Carburetor/EFI Cover)
1212	809958		STUD -(Blower Housing)
1366	841510		DIVERTER, Oil Cooler
1374	841506		SEAL, O-Ring -(Oil Cooler Diverter)




Control Brackets, Springs, Rod, Throttle Control

REF NO	PART NO	QTY	DESCRIPTION
188	692062		SCREW -(Control Bracket) (M8x18mm)
188	841233		SCREW -(Control Bracket) (M6x10mm)
202	846825		LINK, Mechanical Governor
209	845604		SPRING, Governor -(Bronze)
211	809875		SPRING, Governed Idle -(White)
222	846818		BRACKET, Control
227	809984		LEVER, Governor Control
232	843248		SPRING/LINK, Governor
265	691024		CLAMP, Casing
265A	841673		CLAMP, Casing -(Control Bracket)
267	841552		SCREW -(Casing Clamp) (M5x20mm)
271	692541		LEVER, Control
278	842122		WASHER -(Governor Control Lever)
281	690742		PANEL, Control
282	841552		SCREW -(Control Lever) (M5x20mm)
505	844752		NUT -(Governor Control Lever)
561	690713		NUT -(Control Lever)
562	843344		BOLT -(Governor Lever)
663	692056		SCREW -(Control Panel) (M8x14mm)
890A	847155		BRACKET, Support



Crankcase Covers, Camshaft


REF NO	PART NO	QTY	DESCRIPTION
12	846037		GASKET, Crankcase -(Metal Core Gasket)
12A	843969		GASKET, Crankcase -(Metal Core Gasket)
18	844792		COVER, Crankcase
20	841596		SEAL, Oil -(PTO Side)
22	807362		SCREW -(Crankcase Cover/Sump) (M8x50mm)
45	809785		TAPPET, Valve
46	809879		CAMSHAFT
219	809426		GEAR, Governor
220	841608		WASHER -(Governor Gear)
221	841026		CUP, Governor
273	690681		SEAL, O-Ring -(Oil Pump)
439	692154		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly) (Cylinder)
439A	846027		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly) (Crankcase Cover/Sump)
468	690690		SEAL, O-Ring -(Oil Pump Screen)
479	807084		SCREW -(Oil Pump Screen)
523	841007		DIPSTICK
596	691492		SCREW -(Oil Pump)
615A	698290		RETAINER, Governor Shaft
750	841233		SCREW -(Oil Pump Cover) (M6x10mm)
965	809422		COVER, Oil Pump
1017	809421		SCREEN, Oil Pump
1024	845983		PUMP, Oil



Not For Reproduction

Cyclonic Air Cleaner, Intake Elbow

REF NO	PART NO	QTY	DESCRIPTION
11	846502		TUBE, Breather -(Formed Hose)
163	807375		GASKET, Air Cleaner
163A	843117		GASKET, Air Cleaner
290	807357		SCREW -(Intake Elbow)
431A	847171		MANIFOLD, Intake
445A	841497		FILTER, A/C Cartridge
445B	821136		FILTER, A/C Cartridge
536	809670		CLEANER, Air
582	809878		CLAMP, Air Cleaner
601	844405		CLAMP, Hose -(Breather Tube)
601E	846483		CLAMP, Hose -(Purge Line Hose)
717	841886		BRACKET, Air Cleaner
813	807376		CLAMP
968A	842621		COVER, Air Cleaner
1315	847172		HOSE, Air Cleaner
1328	809907		CAP, A/C Rain
1337	807382		SCREW -(Air Cleaner Clamp)
1406	842623		VALVE, Debris
1425	847085		HOSE, Purge Line













Cylinder Heads, Rocker Covers

REF NO	PART NO	QTY	DESCRIPTION
5	846463		HEAD, Cylinder -(Cylinder 1)
5A	846464		HEAD, Cylinder -(Cylinder 2)
7	809730		GASKET, Cylinder Head
11	846502		TUBE, Breather -(Formed Hose)
11A	847173		TUBE, Breather
13	809784		SCREW -(Cylinder Head) (M9x70mm)
21	843464		CAP, Oil Fill
33	844787		VALVE, Exhaust
34	846469		VALVE, Intake
35	845589		SPRING, Valve -(Intake) (Intake) (Pink)
36	845589		SPRING, Valve -(Exhaust) (Exhaust) (Pink)
40	844788		RETAINER, Valve
42	807683		KEEPER, Valve
45	809785		TAPPET, Valve
51	841592		GASKET, Intake -(Intake Manifold)
192	690083		ADJUSTER, Rocker Arm
337	792015		PLUG, Spark
383	19576S		WRENCH, Spark Plug
580	809894		SEAL, O-Ring -(Oil Fill Cap)
601	844405		CLAMP, Hose -(Breather Tube)
635	692076		BOOT, Spark Plug
708	841301		SEAL, O-Ring -(Breather Reed)
798	691492		SCREW -(Rocker Arm) (M6x18mm)
868	691963		SEAL, Valve
883	809872		GASKET, Exhaust
914	807357		SCREW -(Rocker Cover) (M6x40mm)
1022	809732		GASKET, Rocker Cover
1023	809789		COVER, Rocker -(Cylinder #2)
1023A	809731		COVER, Rocker -(Cylinder #1)
1026	809783		ROD, Push -(Intake and Exhaust)
1029	690972		ARM, Rocker
1029A	807323		ARM, Rocker
1077	809729		BRACKET, Lifting
1100	791959		PIVOT, Rocker Arm
1376	806421		SCREW -(Breather Reed Cover)







1036

1330






Cylinders, Piston/Rings/Connecting Rod

REF NO	PART NO	QTY	DESCRIPTION
1	845756		CYLINDER ASSEMBLY
3	841596		SEAL, Oil -(Magneto Side)
12	846037		GASKET, Crankcase -(Metal Core Gasket)
12A	843969		GASKET, Crankcase -(Metal Core Gasket)
15	807392		PLUG, Oil Drain
16	841839		CRANKSHAFT
24	796335		KEY, Flywheel -(Steel)
25	842939		PISTON ASSEMBLY -(.020 Oversize)
25	841837		PISTON ASSEMBLY -(Standard)
26	841932		SET, Ring -(.020 Oversize)
26	809972		SET, Ring -(Standard)
27	807351		LOCK, Piston Pin
28	807361		PIN, Piston
29	841838		ROD, Connecting
32	807363		SCREW -(Connecting Rod)
377	691639		KEY, Timing
404	809436		WASHER -(Governor Crank)
439	692154		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly) (Cylinder)
439A	846027		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly) (Crankcase Cover/Sump)
490	843433		BEARING, Magneto Side
615	809533		RETAINER, Governor Shaft
616	844180		CRANK, Governor
691	809287		SEAL, Governor Shaft
718	690959		PIN, Locating -(Cylinder)
718A	809508		PIN, Locating -(Cylinder Head)
718B	845925		PIN, Locating -(Cylinder)
741	809432		GEAR, Timing
1013	841602		NIPPLE, Oil Filter
1027	842921		FILTER, Oil
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1330	-----		Repair Manual -(Not Available At This Printing)
1378	844795		SET, Washer/Nut -(Flywheel)
1398	842191		COVER, Fuel Pump
1399	690932		SCREW -(Fuel Pump Cover) (M5x10mm)
1400	809894		SEAL, O-Ring -(Fuel Pump Cover)










Electric Starter, Alternator, Regulator, ECM

REF NO	PART NO	QTY	DESCRIPTION
309	845760		MOTOR, Starter
344	841233		SCREW -(Cable Clamp) (M6x10mm)
474	846882		ALTERNATOR -(20 Amp)
480	841233		SCREW -(Tube Clamp) (M6x10mm)
501A	847385		REGULATOR -(20 Amp)
526	690717		SCREW -(Regulator) (M6x30mm)
526A	847149		SCREW -(Regulator) (M6x32mm)
527	690423		CLAMP, Tube
587	846866		CLAMP, Cable
697	690711		SCREW -(Starter Motor) (Drive Cap) (M8x38mm)
893	845758		NUT -(Starter Solenoid)
920	846737		SOLENOID, Starter
1054	280275		TIE, Cable -(Clear, Nylon)
1054A	861206		TIE, Cable -(Black, Nylon)
1119	691552		SCREW -(Alternator) (M4x30mm)
1500	846484		MODULE, Electronic Control -(Not Programmed) (Not Programmed)
1510	841552		SCREW -(Electronic Control Module) (M5x20mm)
1519	19633		CABLE/SOFTWARE, Diagnostic



Engine Gasket Set, Valve Gasket Set, Wire Cover Kit


REF NO	PART NO	QTY	DESCRIPTION
3	841596		SEAL, Oil -(Magneto Side)
7	809730		GASKET, Cylinder Head
20	841596		SEAL, Oil -(PTO Side)
51	841592		GASKET, Intake -(Intake Manifold)
51A	846473		GASKET, Intake -(Intake Manifold/Throttle Body)
163	807375		GASKET, Air Cleaner
163A	843117		GASKET, Air Cleaner
273	690681		SEAL, O-Ring -(Oil Pump)
358	846671		GASKET SET, Engine
439	692154		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly) (Cylinder)
468	690690		SEAL, O-Ring -(Oil Pump Screen)
580	809894		SEAL, O-Ring -(Oil Fill Cap)
652	807084		SCREW -(Support Bracket) (M6x14mm)
652A	807362		SCREW -(Support Bracket) (M8x50mm)
652C	692067		SCREW -(Support Bracket) (M6x12mm)
652B	807421		SCREW -(Support Bracket) (M6x25mm)
868	691963		SEAL, Valve
883	809872		GASKET, Exhaust
1022	809732		GASKET, Rocker Cover
1095	846672		GASKET SET, Valve
1184	690941		NUT -(Support Bracket) (Wire Cover)
1522	846510		COVER, Wire -(Includes Installation Instructions)
1522A	847235		COVER, Wire



Exhaust System, Oxygen Sensors











REF NO	PART NO	QTY	DESCRIPTION
330	593870		SENSOR, Oxygen
437	809743		SCREW -(Exhaust Manifold) (M8x25mm)
613	692062		SCREW -(Muffler) (M8x18mm)
883	809872		GASKET, Exhaust

Not For Reproduction



Flywheel Fans, Air Guides, Stub Shafts, Flywheel

REF NO	PART NO	QTY	DESCRIPTION
23	846836		FLYWHEEL
24	796335		KEY, Flywheel -(Steel)
73	841840		SCREEN, Rotating
74	809947		SCREW -(Rotating Screen)
215	846455		GUIDE, Air -(Cylinder #1)
215A	846456		GUIDE, Air -(Cylinder #2)
215B	809897		GUIDE, Air -(Cylinder #2)
215D	846458		GUIDE, Air -(Valley)
215C	809738		GUIDE, Air -(Cylinder #1)
363	19203		PULLER, Flywheel
849B	807421		SCREW -(Stub Shaft) (M6x25mm)
890B	809987		BRACKET, Support
934	807421		SCREW -(Fan Retainer) (M6x25mm)
1005A	846995		FAN, Flywheel
1006	846495		RETAINER, Fan
1070	807435		SCREW -(Flywheel Fan) (M6x20mm)
1332	809948		WASHER -(Rotating Screen)
1334	807435		SCREW -(Air Guide) (M6x20mm)
1334A	841233		SCREW -(Air Guide) (M6x10mm)
1334B	807084		SCREW -(Air Guide) (M6x14mm)
1334C	690677		SCREW -(Air Guide) (M4x12mm)
1334D	692062		SCREW -(Air Guide) (M8x18mm)
1334E	692056		SCREW -(Air Guide) (M8x14mm)
1369	842858		GUARD, Flywheel Fan
1370	841233		SCREW -(Flywheel Fan Guard) (M6x10mm)
1371	841537		NUT -(Flywheel Fan Guard)
1372	809946		STUD -(Rotating Screen)
1378	844795		SET, Washer/Nut -(Flywheel)
1413	846457		SENSOR, Speed
1502	846459		SCREW -(Speed Sensor) (M5x10mm)
1502A	846868		SCREW -(Speed Sensor) (M4x18mm)



Fuel Hoses, Fuel Pump, Mounting Bracket

REF NO	PART NO	QTY	DESCRIPTION
187	791745		LINE, Fuel -(23 Inches)(Cut To Required Length)
187	791766		LINE, Fuel -(15 Inches Long)(Cut to Required Length)
187A	846475		LINE, Fuel
187B	846823		LINE, Fuel
240	845125		FILTER, Fuel
265	691024		CLAMP, Casing
267	841552		SCREW -(Casing Clamp) (M5x20mm)
385	841233		SCREW -(Fuel Pump) (M6x10mm)
387	846824		PUMP, Fuel
480	841233		SCREW -(Tube Clamp) (M6x10mm)
527	690423		CLAMP, Tube
601B	791850		CLAMP, Hose -(Green)
601C	691038		CLAMP, Hose -(Black)
652	807084		SCREW -(Support Bracket) (M6x14mm)
717	841886		BRACKET, Air Cleaner
717A	847170		BRACKET, Air Cleaner
788	847087		BRACKET, Fuel Pump
890	846506		BRACKET, Support
961	692056		SCREW -(Air Cleaner Bracket) (M6x14mm)
964	590799		CAP, Connector
1480	593852		INJECTOR, Fuel
1485	593890		MODULE, Fuel
1490	807084		SCREW -(Fuel Injector) (M6x14mm)
1497	846505		BRACKET, Fuel Module
1498	807084		SCREW -(Fuel Module Bracket)
1503	594618		SCREW -(Fuel Module) (1/4-20x.5)











Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	791244	1	Replacement Short Block
	61E3770009	1	Replacement Engine
	-----		Top No-Load Speed: 4000 -Trim: J1

Not For Reproduction

Wire Harness, Throttle Body, Intake Manifold

Mfg. No: 61E377-0009-J1



Wire Harness, Throttle Body, Intake Manifold

REF NO	PART NO	QTY	DESCRIPTION
50	846503		MANIFOLD, Intake
51	841592		GASKET, Intake -(Intake Manifold)
51A	846473		GASKET, Intake -(Intake Manifold/Throttle Body)
95	593897		SCREW -(Throttle Valve)
98	797156		KIT, Idle Speed
130	846808		VALVE, Throttle
163	807375		GASKET, Air Cleaner
320	593902		RELAY(S)
333	846490		ARMATURE, Magneto -(Cylinders 1 and 2)
334	841552		SCREW -(Magneto Armature) (M5x20mm)
480	841233		SCREW -(Tube Clamp) (M6x10mm)
486	593901		FUSE
527	690423		CLAMP, Tube
635	692076		BOOT, Spark Plug
789	847441		HARNESS, Wiring -(Intake Manifold) -Used Before Code Date 16122300
789C	847408		HARNESS, Wiring -(Intake Manifold) -Used After Code Date 16122200
1054	280275		TIE, Cable -(Clear, Nylon)
1054A	861206		TIE, Cable -(Black, Nylon)
1130	841590		STUD -(Intake Manifold)
1174	842067		NUT -(Intake Manifold)
1357	846822		SLEEVE, Fuel Line -(Cut To Required Length)
1482	846807		BODY, Throttle
1483	593895		COVER, Dust
1484	847169		SCREW -(Dust Cover)
1486	593905		SENSOR, Temperature/Manifold Absolute Pressure (MAP)
1487	847337		COVER, Fuse
1487A	847334		COVER, Fuse
1488	593899		COVER, Diagnostic
1489	807435		SCREW -(TEMP/MAP Sensor) (Intake Manifold)
1491	807435		SCREW -(Throttle Body) (M6x20mm)
1491A	807084		SCREW -(Throttle Body) (M6x14mm)
1504	841233		SCREW -(Fuse Cover) (M6x10mm)
1537	703460		NUT -(Fuse Cover)
1538	847332		STUD -(Fuse Cover)
1539	847333		WASHER -(Fuse Cover)

