




SPARE PARTS LIST

BLOWERS

132 HBV, 1990-11

A



*compl 530 01 41-62


COVER

132 HBV, 1990-11

Part No	Description	Remark	QTY KIT
530 01 07-29	HUB CAP		1
530 01 08-97	FUEL PICK UP ASSY 1400/1700		1
530 01 41-60	HANDLE		1
530 01 41-62	TANK		1
530 01 56-35	SCREW		1
530 01 56-35	SCREW		1
530 01 57-02	CLIP		1
530 01 58-13	SCREW		1
530 01 58-14	SCREW		1
530 01 58-40	SCREW		1
530 02 47-72	SPRING		1
530 02 69-94	ANTIVIBRATION ELEMENT		1
530 02 75-97	SPRING		1
530 02 90-72	TRIGGER		1
530 02 91-11	SPACER		1
530 02 91-12	AIR FILTER		1
530 02 91-17	BUTTON		1
530 02 91-29	INSULATOR		1
530 02 91-30	INSULATOR		1
530 02 92-95	INSULATOR		1
530 02 94-25	CABEL		1
530 02 94-26	CABLE		1
530 02 97-00	COVER		1
530 02 97-01	COVER		1
530 02 97-02	COVER		1
530 06 92-47	HOSE		1
530 06 92-92	SWITCH		1
530 09 47-12	HANDLE ASSY		1

B

*** compl 530 06 92-77**





CYLINDER PISTON

132 HBV, 1990-11

Part No	Description	Remark	QTY KIT
530 01 09-60	CONNECTING ROD		1
530 01 22-38	CYLINDER		1
530 01 51-62	CIRCLIP		1
530 01 52-39	SCREW		1
530 01 57-75	SCREW		1
530 01 58-16	SCREW		1
530 01 91-61	GASKET		1
530 01 91-68	SLEEVE		1
530 02 58-75	PISTON RING		1
530 02 91-05	CLAMP		1
530 02 91-16	SPRING		1
530 02 91-46	CABLE ASSY		1
530 02 92-27	NET		1
530 02 92-28	CLAMP		1
530 02 94-04	AIR CONDUCTOR		1
530 02 94-25	CABEL		1
530 03 91-37	IGNITION MODULE		1
530 06 92-77	PISTON		1
530 06 92-93	MUFFLER		1
530 06 93-04	HEAT PROTECTOR		1


C



Part No	Description	Remark	QTY KIT
530 00 17-33	NUT		1
530 01 41-57	IMPELLER		1
530 01 41-58	BLOWER HOUSING LOWER		1
530 01 53-67	SCREW		1
530 01 54-41	WASHER		1
530 01 54-96	SCREW		1
530 01 56-47	PEN		1
530 01 56-67	SPRING		1
530 01 56-72	SPRING		1
530 01 57-69	SCREW		1
530 01 57-75	SCREW		1
530 01 58-05	SCREW		1
530 01 58-15	SCREW		1
530 01 58-15	SCREW		1
530 01 58-18	WASHER		1
530 01 58-23	SCREW CPL		1
530 01 91-67	O-RING		1
530 02 75-23	RETAINER		1
530 02 75-23	RETAINER		1
530 02 75-69	STARTER HANDLE		1
530 02 90-69	HOUSING		1
530 02 91-10	RING		1
530 02 91-18	HUB		1
530 02 91-19	SCREW		1
530 02 91-73	BAND		1
530 02 91-82	HOLDER		1
530 02 93-95	RECOIL SPRING		1
530 03 21-08	BEARING		1
530 06 92-32	STARTER ROPE		1
530 06 92-91	STARTER PULLEY		1
530 09 47-10	FAN HOUSING		1
530 09 47-15	DOOR BVL320		1

D

***compl 530 03 52-64**




CARBURETOR DETAILS

132 HBV, 1990-11

Part No	Description	Remark	QTY KIT
530 03 50-28	PEN		1
530 03 50-31	LEVER		1
530 03 51-06	NEEDLE VALVE		1
530 03 51-51	GASKET		1
530 03 51-64	GASKET		1
530 03 51-66	DIAPHRAGM PUMP		1
530 03 51-78	SCREEN		1
530 03 51-88	SPRING		1
530 03 52-03	SCREW		1
530 03 52-08	SPRING		1
530 03 52-14	SPRING		1
530 03 52-64	REPAIR KIT		1
530 03 52-67	DIAPHRAGM		1
530 03 52-68	NEEDLE		1

E




ENGINE

132 HBV, 1990-11

Part No	Description	Remark	QTY KIT
530 01 40-16	CRANKCASE ASSY		1
530 01 40-33	CRANKSHAFT ASSY		1
530 01 41-56	CRANKCASE		1
530 01 51-26	KEY		1
530 01 52-41	SCREW		1
530 01 52-54	SPRING		1
530 01 53-06	SCREW		1
530 01 56-26	WASHER		1
530 01 57-71	SCREW		1
530 01 57-87	RETAINER RING		1
530 01 57-88	SPACER		1
530 01 57-89	RETAINER RING		1
530 01 58-49	SCREW		1
530 01 91-58	SEALING RING		1
530 01 91-64	GASKET		1
530 01 91-65	SEALING		1
530 01 91-66	GASKET		1
530 02 38-17	SPRING		1
530 02 75-28	SPACER		1
530 02 75-93	REED		1
530 02 75-94	REED STOP		1
530 02 90-70	BLOCK REED		1
530 02 91-13	GROUND WIRE		1
530 02 91-14	CHOKE SHUTTER		1
530 02 91-15	PLATE		1
530 02 91-76	SPACER		1
530 02 94-26	CABLE		1
530 03 21-02	BEARING		1
530 03 21-03	BEARING		1
530 03 52-63	CARBURETTOR		1
530 03 91-36	FLYWHEEL ASSY		1

F



TUBE

132 HBV, 1990-11

Part No	Description	Remark	QTY KIT
530 09 44-76	TUBE		1
530 09 46-52	TUBE		1
530 09 46-62	BLOWER NOZZLE		1
530 09 46-64	TUBE		1
530 09 47-64	ELBOW		1
530 09 47-73	COLLECTION BAG		1
530 35 14-55	TUBE		1