




SPARE PARTS LIST

HEDGE TRIMMERS/POLE HEDGE
TRIMMERS

132 LD, 1993-05

A

compl 531 00 47-01




CLUTCH & OIL PUMP



132 LD, 1993-05

Part No	Description	Remark	QTY KIT
531 00 47-01	CUTTER ASSY		1
531 00 47-02	CONNECTION		1
531 00 47-03	GEAR HOUSING		1
531 00 47-04	PLATE GUIDE		1
531 00 47-05	NIPPLE		1
531 00 47-06	PINION		1
531 00 47-07	CRANK GEAR		1
531 00 47-08	PLATE		1
531 00 47-09	ROD ASSY		1
531 00 47-09	ROD ASSY		1
531 00 47-10	BLADE		1
531 00 47-11	PLATE		1
531 00 47-12	FELT		1
531 00 47-13	BLADE		1
531 00 47-14	GEAR HOUSING		1
531 00 47-15	WASHER		1
531 00 47-15	WASHER		1
531 00 47-16	SCREW		1
531 00 47-17	SCREW		1
531 00 47-18	HOLDER		1
531 00 47-19	DECAL		1
724 12 19-01	SCREW CRPANM		1
724 33 25-01	SCREW		1
724 33 31-01	SCREW		1
725 23 29-71	SCREW EHHM		1
725 23 31-71	SCREW EHHM		1
725 23 70-71	SCREW EHHM		1
725 23 74-71	SCREW EHHM		1
731 71 14-51	HEXAGON NUT FLANGE		1
732 21 16-01	LOCK NUT		1
738 21 01-03	BALL BEARING		1
738 21 98-01	BALL BEARING		1
738 21 98-01	BALL BEARING		1

B



* compl 531 00 47-20



GEAR HOUSING

132 LD, 1993-05

Part No	Description	Remark	QTY KIT
531 00 22-11	ADAPTER		1
531 00 40-25	BUSHING		1
531 00 47-20	BEVEL GEAR		1
531 00 47-21	HOUSING		1
531 00 47-22	NIPPLE		1
531 00 47-24	SHAFT		1
531 00 47-25	PINION GEAR		1
531 00 47-26	DRIVE SHAFT		1
531 00 47-27	TUBE		1
531 00 47-28	DECAL		1
531 00 47-29	DECAL		1
531 00 47-53	STATOR		1
725 23 27-71	SCREW EHHM		1
725 23 33-71	SCREW EHHM		1
735 31 11-41	RETAINER RING		1
735 31 25-10	CIRCLIP		1
735 31 31-10	CIRCLIP		1
738 21 98-00	BALL BEARING		1
738 21 99-00	BALL BEARING		1
738 21 99-01	BALL BEARING		1
738 22 01-19	BALL BEARING		1