




SPARE PARTS LIST

HEDGE TRIMMERS/POLE HEDGE
TRIMMERS

500 H, 19960900001-Current


E



HANDLE

500 H, 19960900001-Current


Part No	Description	Remark	QTY KIT
531 00 30-29	SCREW		1
531 00 30-30	SCREW		1
531 00 30-30	SCREW		1
531 00 30-33	PROTECTOR		1
531 00 30-40	SPRING		1
531 00 30-50	HANDLE		1
531 00 30-51	HANDLE		1



CUTTING EQUIPMENT

500 H, 19960900001-Current

Part No	Description	Remark	QTY KIT
531 00 30-31	SCREW		1
531 00 30-47	PROTECTOR 550 MM		1
531 00 30-72	PLATE		1
531 00 30-73	SCREW		1
531 00 31-75	BLADE		1




COVER

500 H, 19960900001-Current

Part No	Description	Remark	QTY KIT
531 00 30-26	SCREW		1
531 00 30-28	SCREW		1
531 00 30-36	CLAMP		1
531 00 30-48	HOUSING		1
531 00 30-49	MOULDING		1
531 00 30-53	LEVER		1
531 00 30-60	WIRE		1
531 00 30-66	CABLE		1
531 00 30-67	CLAMP		1
531 00 30-69	SCREW		1
531 00 31-79	GROMMET		1


B



MOTOR

500 H, 19960900001-Current

Part No	Description	Remark	QTY KIT
531 00 30-27	SCREW		1
531 00 30-37	O-RING		1
531 00 30-54	ENGINE		1
531 00 30-62	CABLE		1
531 00 30-63	CABLE		1
531 00 30-64	CABLE		1
531 00 30-65	CAPACITOR		1
531 00 30-68	BRUSH		1
531 00 31-81			1




GEAR HOUSING

500 H, 19960900001-Current

Part No	Description	Remark	QTY KIT
531 00 30-34	SEALING		1
531 00 30-35	SWITCH		1
531 00 30-39	WASHER		1
531 00 30-39	WASHER		1
531 00 30-41	SPRING		1
531 00 30-44	WASHER		1
531 00 30-52	GEAR HOUSING		1
531 00 30-59	LEVER		1
531 00 30-61	PIN RETAINING SCREW		1

D

compl 531 00 30-74



GEAR HOUSING

500 H, 19960900001-Current

Part No	Description	Remark	QTY KIT
531 00 30-38	PIN RETAINING SCREW		1
531 00 30-42	RETAINER RING		1
531 00 30-43	WASHER		1
531 00 30-55	GEAR		1
531 00 30-58	HOLDER		1
531 00 30-70	RING		1
531 00 30-71	RING		1
531 00 30-74	GEARBOX		1
531 00 31-76	SHAFT		1
531 00 31-77	CLUTCH		1
531 00 31-78	BEARING		1
531 00 31-80	BEARING		1